



Powered By
SHUFFLE
WALLET

LOCATOR DEVICE USER GUIDE



Works with Android
Find Hub



Works with
Apple Find My

Overview introduction

The device integrates Google Find My Device Network and Apple Find My Network providing a secure and user-friendly solution for finding belongings.

Collaborative positioning is carried out by leveraging a vast anonymous network composed of Android and Apple devices. It can easily locate keys, wallets, and more, with security as its top priority. Designed for user convenience, it helps you say goodbye to lost items and simplifies daily life.

How To Pair (iOS device)

Note: iOS or macOS with the latest version.

iOS Pairing Name: **Sling Tag** or **Minimum Card**

- 1.1 Place the device next to your Apple device like iPhone.
- 1.2 Turn on Bluetooth on iPhone and connect to the Internet.
- 1.3 Press and hold the button for 2 seconds, and you will hear a beep indicating successful power-on.
- 1.4 Open the 'Find My' app.
- 1.5 In 'Find My' app, Tap '+', then 'Add Other Item'.
- 1.6 Once the device is located, tap 'connect'.
- 1.7 Enter a name and choose an emoji for the device. Tap 'Continue'.
- 1.8 Find My will ask for confirmation to add the device to your Apple ID. Tap 'Agree'.
- 1.9 Tap 'Finish' and the device will be set up and ready to be used.

How To Pair (Android device)

Note: It requires an Android smartphone that supports Google Play Services and runs on Android 9.0 or later.

Android Pairing Name:Smart Tag

2.1 Search for "Find Hub" in the Google Play Store, download and install it.

2.2 Ensure that your phone has location services enabled, Bluetooth turned on, is connected to the internet, logged into a Google account, and has the "Find My Device" feature activated.

2.3 Open "Find Hub" app.

2.4 Press and hold the button for 2 seconds, and you will hear a beep indicating successful power-on.

2.5 Within a few seconds, a pop-up window with a name and image will automatically appear at the bottom of the phone screen. Tap "Connect".

2.6 When the "Use Responsibly" pops up on your phone, tap "Accept and Continue" – the device will emit a "beep-beep" melody.

2.7 Tap "Done" to complete the pairing successfully.

Battery

The device contains a coin shaped battery. During the product's lifespan, it may be necessary to replace the battery. By observing the correct negative and positive connections, only replace batteries of the same type (CR2032) and rating.

Battery replacement

- 3.1 Pry open the back cover.
- 3.2 Replace a new battery.
- 3.3 Close the back cover.

Additional Tips

- 4.1 To switch from working mode to disabled mode (Flight Mode), simply power off the device: press and hold the button for approximately 7 seconds, then release it once the device emits a beep pattern of "beep, beep-beep, beep-beep-beep".
- 4.2 To switch from disabled mode (Flight Mode) to working mode, please power on the device again: press and hold the button for approximately 2 seconds, then release it once the device emits a single "beep"; the device will enter pairing mode, and note that if no connection is established within 2 minutes, it will time out and require a restart.
- 4.3 Factory Reset: Press and hold the button – do not release it after hearing the continuous beep pattern of "beep, beep-beep, beep-beep-beep"; keep holding until a long beep is heard, then release. Note that a timeout will occur after 2 minutes.
- 4.4 To remove this device from your Apple device: Open the "Find My" app, select "Items", tap on the device, then scroll down and tap "Remove This Device".
- 4.5 To remove this device from your Android device: Open the "Find My Device" app, tap on the device you want to remove, then tap the "Settings" button in the top-right corner. Tap "Remove from Find My Device" at the bottom of the interface, and then tap

the "Remove" button. Once the device is removed successfully, it will emit a "beep-beep" prompt, and a "Device Removed" pop-up will appear on your phone.

4.6 If this device fails to connect to the App, follow the instructions in Section 4.3 to perform a factory reset, then restart the pairing process.

Important matters

The device contains delicate electronic parts, including a battery to avoid damage, loss of function, or potential harm, please refrain from dropping, hitting, puncturing, crushing, disassembling, exposing it to extreme heat or liquids, or placing it in areas with a high concentration of industrial chemicals.



WARNING: Do not swallow the battery; There is a chemical burn hazard.

Choking Hazard Warning

The device, its battery compartment door, the battery itself, and the case may pose a choking hazard or cause injury to small children. Please keep these items out of reach of young children.

The device, the battery hatch, the battery itself, and the enclosure may pose a choking hazard or cause injury to young children. Keep these out of the reach of small children.

Medical Device Interference

The device contains components and radios that emit electromagnetic fields, as well as magnets. These elements may potentially interfere with pacemakers, defibrillators, or other

medical devices. To ensure safety, maintain a safe distance between your medical device and the device. We strongly advise consulting your physician and the manufacturer of your medical device for information that is specific to your situation. If you suspect that the device is interfering with your pacemaker defibrillator or any other medical device, discontinue its use immediately.

Important Handling Guidelines

It's normal for the device to show discoloration with regular use. To clean it, use a soft, dry, lint-free cloth.

Avoid applying pressure with sharp objects on the rubber seal or the battery terminal contacts inside the device.

Do not allow moisture to enter any openings or use aerosol sprays, solvents or abrasive materials to clean the device.

Legal notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.